


Voice Coil Motors with Analog Feedback

BEI Kimco (and others) provide voice coil motors with analog (Hall Effect) feedback. These motors may be ordered with a .1 to 3.3v output range and 2kHz internal filter. These settings will optimize their performance with the the SilverSterling™ controller family.

Driver Connections


The Voice Coil Motor has two wires associated with the motor. These are typically color coded as RED for plus (+) and WHITE for minus (-). A positive current moves the shaft in the positive reference direction (see BEI documentation). The SilverSterling™ supports the connection of either a single driver channel (5A continuous) or both driver channels (10A continuous). The input power current is limited to 5A average, but the drivers act switched mode converters. Operation of a 12 or 24v actuator from a 48v supply will allow the full 10A capability (usually limited by the thermal capability of the motor). The driver circuit in the SilverSterling includes output inductors. These inductors allow the two phase outputs to be directly connected when operating a DC motor. If the higher currents are needed, connect Motor A+ to Motor B+, Motor A- to Motor B-. For smaller motors use Motor A+ and Motor A- connections.

If the motor is ordered with the sensor output configured for 0.1 to 3.3v outputs, the motor can



be directly connected to the motor port with no voltage divider needed. The driver should be ordered with the -B option to remove an internal 1k pullup so the analog sensor can drive the analog input over the full input range.

If the motor is ordered with the 0.5 to 4/5v outputs, a voltage divider will be needed. These connections can be made directly to a 15 pin male high density D-sub connector or the QCI-BO-M1 breakout board. The connections are shown below:



Sensor Connections

The BEI linear actuators typically have four (4) wires associated with the analog feedback sensor. These are +5v, Ground, Analog out, and Vp. Vp is used at the factory to configure the gain and offset of the sensor and should not be connected to anything in the customer installation. The 5v power may be connected to the 5v output on the QCI-BO-S1 break out board; the Ground connection should be connected to the Logic Ground connection. The output needs to use a voltage divider if the feedback sensor output range exceeds the 3.3v used for the IO. (Note: the actuator can be ordered with the output sensor range set to 0.1v or 3.3v to eliminate the need for a voltage divider. It should be ordered with the 2kHz sensor bandwidth for optimal performance).

The voltage divider is accomplished using a 750 ohm resistor in series with the sensor output line and connected to IO4 (the analog input) and a 3 kohm resistor from the Analog input (IO4) to Logic Ground. Some noise filtering and more accurate readings require the addition of a .005 to .01uF capacitor. This capacitor should have low leakage and low dielectric absorption. A film capacitor or a COG ceramic should work well.

The Motor Memory input has a 3.3k pullup to 3.3v, which should not affect the direct drive sensor output (.1 to 3.3v) but will affect a voltage divider if not buffered.

Initialization Code

The controller should be initialized using the Linear DC Motor using MEM Pin.qcp file included in this application note. You will also need a devAux file for your linear actuator. (Contact Support.).

| Line# Oper | Label | Command |
|---------------|------------------|--|
| 1:REM | | <pre>===== DC MOTOR Initialization - SilverSterling with -B option only ===== These programs contains the initialization commands. It can be edited directly or through Tools -> Initialization Wizard Download the program at the end of the wizard or by pressing the "Download" button in the Program Info Toolbar. Reboot the device. (See the description in Scaling for more details)</pre> |
| 2:REM | | <pre>===== *** Communications (COMM) =====</pre> |
| 3:REM | | ***COMM:Identity |
| 4:IDT | | Identity: Unit ID = 16, Group ID = 20 |
| 5:REM | | ***COMM:Protocol |
| 6:PRO | | Protocol = 8-Bit ASCII 2 Stop Bits, No Parity |
| 7:REM | | ***COMM:Serial Interface |
| 8:SIF | | Serial Interface = RS485 |
| 9:REM | | ***COMM:Baud Rate |
| 10:BRT | | Baud Rate = 57.6K |
| 11:REM | | ***COMM:ACK Delay |
| 12:ADL | | ACK Delay = Auto |
| 13:REM | | Load and Run Flash Seq if there was a Factory Block fault |
| 14:JRE | | Jump to "FAC BLK OK" When "User[41]" = 0 |
| 15:LRP | | Load And Run Program: Program = "Factory Block Fault" |
| 16:REM | FAC BLK OK | Factory Block Ok |
| 17:REM | | <p>Startup Error Conditions.</p> <p>A special "Startup" Kill Motor Recover program is used for only a short time during initialization. It allows the motor to come up to a point where it can communicate with a host before it gets shut down by an existing error condition.</p> <p>The following commands setup a minimum set of error conditions and configure the Startup Kill Motor Recovery to be run in the event of an existing error.</p> |
| 18:KMR | | Kill Motor Recovery: Program = "Startup Recovery" |
| 19:KMC | | Kill Motor Conditions: If Temp/Driver Enable Fault or Over Voltage TRUE or Low Voltage TRUE |
| 20:ERL | | Error Limits: Moving Limit = 0 counts Holding Limit = 0 counts Delay to Holding = 30 mSec |
| 21:LVT | | Low Voltage Trip = 10 volts |
| 22:REM | | Startup Power Low Recovery This is similar to the above explained Startup Kill Motor Recovery. |
| 23:PLR | | Power Low Recovery: Program = "Startup Recovery" |
| 24:REM | | Read the factory set ADC calibration data from NV memory. At the analog inputs are factory calibrated. This command reads the calibration data from NV memory and calibrates the ADC. |
| 25:CAI | | Calibrate Analog Input from Non-Volatile |
| 26:REM | | Phase Align torque limits |

Set the identity, protocol, and baud rate as needed.

Error limits are set to 0 to disable them when starting up. These can be enabled at a later time by setting them to a non-zero value. The "running" torque level is available for 30 ms following a motion to allow the motion to complete while minimizing the heating if the actuator is not able to make the motion.

| Line# Oper | Label | Command |
|---------------|-------|--|
| 27:TQL | | Torque Limits: Closed Loop Holding = 0 Closed Loop Moving = 0 Open Loop Holding = 0 Open Loop Moving = 0 |
| 28:GOL | | Go Open Loop |
| 29:SLC | | Single Loop Control |
| 30:REM | | ===== |
| | | *** Motor (MOTOR) |
| | | ===== |
| 31:REM | | The commands: Motor Constants (MCT) Phase Advance (PAC) are set dependent on input voltage by a factory derived formula. These commands should only be edited by the Initialization Wizard. |
| 32:DMD | | Disable Motor Driver |
| 33:REM | | Set mode 2.1 enables DC motor operation. Must be done before motor drive is enabled |
| 34:SMD | | Set Mode: DC Motor Mode Enable |
| 35:REM | | Set mode 7 to select analog feedback from MEM 1=IO4, 2=MEM |
| 36:SMD | | Set Mode extended |
| 37:REM | | Set mode 8 to select analog cutoff frequency 0 120 uS 1 240 uS 2 360 uS 3 .5 mS 4 1mS 5 2 ms 6 5 ms 7 10ms 8 20ms 9 40ms |
| 38:SMD | | Set Mode extended |
| 39:REM | | Set mode 5 filter value sets the filter value used to filter the DC_MOTOR drive voltage (only DC motor mode) |
| 40:SMD | | Set Mode: DC Motor PWM Filter 3999 Hz |
| 41:REM | | **MOTOR:Motor And Phase Advance Constants |
| 42:MCT | | Motor Constants: Auto |
| 43:REM | | Phase Advance Constants This command is edited the same time MCT is edited. The edit dialog box does both at the same time. |
| 44:PAC | | Phase Advance Constants |
| 45:REM | | Set overvoltage to no more than 4v above the voltage for which the unit was initialized |
| 46:OVT | | Over Voltage Trip = Auto |
| 47:REM | | ===== |
| | | *** Servo Tuning (SERVO) |
| | | ===== |
| 48:REM | | **SERVO:Filter Constants |
| 49:FLC | | Filter Constants: Default Settings |
| 50:REM | | **SERVO:Control Constants |
| 51:CTC | | Control Constants: Default Settings |
| 52:DLY | | Delay for 100 mSec |
| 53:REM | | ===== |
| | | *** Motion (MOTION) |
| | | ===== |
| 54:REM | | Set the target to the position (Potentiometer feedback = absolute positioning) |
| 55:TTP | | Target to Position |

Line 34 puts the driver into the DC motor mode of operation (defaults to an encoder feedback).

Line 36 selects feedback from the MEM pin on the motor port (or from IO4)

Line 38 sets a 240 us filter (sampling every 40 us)

Line 40 adds a filter to the output of the torque command.

Line 49 and 51 contain the main system tuning parameters. These will need to be adjusted according to the actuator used, the load

attached, and the desired operation of the system.

| | |
|--------|---|
| 56:REM | With the motor in DC mode, not alignment is needed - this does not need the "encoder" to settle. |
| 57:GCL | Go Closed Loop |
| 58:REM | **MOTION:Torque Limits |
| 59:TQL | Torque Limits: Closed Loop Holding = 6000 Closed Loop Moving = 30000 Open Loop Holding = 0 Open Loop Moving = 0 |
| 60:AHC | Anti-Hunt Constants: Anti-Hunt Disabled |
| 61:REM | **MOTION:Set S-Curve Factor |
| 62:SCF | S-Curve Factor = 0 |
| 63:REM | ===== *** Error Limits(LIMITS) ===== |
| 64:REM | Disable KMC we can change values |
| 65:KMC | Kill Motor Conditions: If Temp/Driver Enable Fault |
| 66:REM | **LIMITS:Low Voltage Trip |
| 67:REM | Temporarily disable the limits we are about to change |
| 68:LVT | Low Voltage Trip = 10 volts |
| 69:REM | **LIMITS:Over Voltage Trip BEI coil limited to 30v, so hard code the limit |
| 70:OVT | Over Voltage Trip = 53 Volts |
| 71:REM | **LIMITS>Error Limits |
| 72:KMR | Kill Motor Recovery: Program = "Kill Motor Recovery" |
| 73:PLR | Power Low Recovery: Program = "Power Low Recovery" |
| 74:REM | Set maximum end of travel limits |
| 75:WRP | Write 1500 to "Positive limit[26]" Register |
| 76:WRP | Write -1500 to "Negative limit[25]" Register |
| 77:SSL | Soft Stop Limits: "Negative limit[25]" Register for Minimum "Positive limit[26]" Register for Maximum |
| 78:REM | ===== *** Misc (MISC) ===== |
| 79:REM | **MISC:Set Digital Input Filters |
| 80:DIF | Digital Input Filter: "All I/O Lines" = 10 mSec |
| 81:DDB | Disable Done Bit |
| 82:MDC | Modulo Clear |
| 83:REM | **MISC:Start Location of User Program |
| 84:LRP | Load And Run Program: Load and Run Program @NV Memory Location=512 |

Line 59 sets the torque limits. The holding torque is only about 1/5 of the peak torque in this example.

Lines 75, 76, and 77 set up soft limits to prevent motions from asking for more motion than the actuator can provide. These may be adjusted for your particular application.

| | |
|--------|---|
| 55:REM | **MOTION:Torque Limits |
| 56:TQL | Torque Limits: Closed Loop Holding = 6000 Closed Loop Moving = 30000 Open Loop Holding = 0 Open Loop Moving = 0 |
| 57:AHC | Anti-Hunt Constants: Anti-Hunt Disabled |
| 58:REM | **MOTION:Set S-Curve Factor |
| 59:SCF | S-Curve Factor = 0 |
| 60:REM | ***** *** Error Limits(LIMITS) ***** |
| 61:REM | Disable KMC we can change values |
| 62:KMC | Kill Motor Conditions: If Temp/Driver Enable Fault |
| 63:REM | **LIMITS:Low Voltage Trip |
| 64:REM | Temporarily disable the limits we are about to change |
| 65:LVT | Low Voltage Trip = 10 volts |
| 66:REM | **LIMITS:Over Voltage Trip BEI coil limited to 30v, so hard code the limit |
| 67:OVT | Over Voltage Trip = 53 Volts |
| 68:REM | **LIMITS>Error Limits |
| 69:KMR | Kill Motor Recovery: Program = "Kill Motor Recovery" |
| 70:PLR | Power Low Recovery: Program = "Power Low Recovery" |
| 71:REM | Set maximum end of travel limits |
| 72:WRP | Write 1600 to "Positive limit[26]" Register |
| 73:WRP | Write -1600 to "Negative limit[25]" Register |
| 74:SSL | Soft Stop Limits: "Negative limit[25]" Register for Minimum "Positive limit[26]" Register for Maximum |
| 75:REM | ***** *** Misc (MISC) ***** |
| 76:REM | **MISC:Set Digital Input Filters |
| 77:DIF | Digital Input Filter: "All I/O Lines" = 10 mSec |
| 78:DDB | Disable Done Bit |
| 79:MDC | Modulo Clear |
| 80:REM | **MISC:Start Location of User Program |
| 81:LRP | Load And Run Program: Load and Run Program @NV Memory Location=512 |

Line 56 sets the holding and moving torque limits. The voice coil motors may have a fairly high ratio of peak to average allowable current. They will become overheated if operated continuously at the peak rated currents.

Lines 72 through 74 provide soft limits for the requested motions to make sure that they do not exceed or come too close to the limits of the position sensor. Exceeding the limits can lock the actuator at the hardware feedback limit. With a requested (Target) position greater than available

feedback values can cause very rapid heating as the servo Position is unable to reach the Target. The Soft Stop Limits prevents this from happening.