

Panasonic HMI

Contact Information

Panasonic Electric Works Corporation of America
908 464 3550

<http://pewa.panasonic.com/acsd/motion-control/products/hmis.php>

Supported Protocols

Use the following protocol to interface an Panasonic HMI to a QCI servo controller.

- Modbus RTU (see our website for application note “QCI-AN038 Modbus Protocol”).

The above protocol allows the HMI to read and write to our registers. The HMI’s variables are thus mapped to our registers. See the above application notes for examples.